

Legend to Vehicle Reference List

Heed all indexes! - Symbols and #'s must be followed !

no install Profi must not be installed in this car.

+ Profi can be installed to this anchor point without vehicle alteration.

S Stock seat not approved. For installation of tail strap to this anchor point, use only special seats, tested and approved by SCHROTH. For SCHROTH tested and approved special seats see list below.

10) Index "S" do not refer to vehicles equipped with RECARO front seats ("sport seats").

15) Installation of tail strap to anchor point "E" instead of "D".

17) Two adapters [Part No. 0015X (X refers to webbing color)] are **strictly** required and must be installed at **both** sides of the lap belt. Must be purchased in addition.

19) Because of needed inner anchor point modification, installation kit (Part No. 00095) is **strictly** required. Must be purchased in addition.

27) To avoid release of the pyrotechnic seat pretensioning devices the battery has to be disconnected 10 minutes before starting installation.

35) If stock 3-point belt should be removed from the car **never** remove stock seat belt buckle as there is a safety device included (VW-description: lunar module) which **never** must be removed from the car.



This product is not designed and tested to be used with HANS® or other head and neck restraints e.g. Hutchens device.

Shoulder belts may slip off the HANS® and crotch straps e.g. of a Hutchens device cannot be properly attached to the lap belt. Malfunction can result in serious personal injuries or death.

If stock seats with integrated side airbags or seat-based sensors are being replaced by aftermarket seats care is necessary to ensure that the entire vehicle safety systems are not compromised. Elimination of seat based airbags sensors by swapping seats could result in a faulty deployment and/or non-function of airbags and permanent illumination of dashboard airbag system warning light. Buckle-pretensioners must never be removed from the vehicle with or without the seat without being secured against unintended firing. Removing buckle-pretensioners from the car also may disturb the function of other safety devices including the front airbags. Heed all instructions and information given in the vehicle's Owner Manual. Before changing seats, check with the vehicle manufacturer to see if your factory provided seats are so equipped, and if so, what provisions and precautions are necessary to preserve factory safety systems.

List of Approved Special Seats

COBRA SUPAFORM: Cobra S, Instyle/LS, Montreaux

CORBEAU EQUIPE: Avanti Recliner, GTB Recliner, GTS Recliner

FLOFIT: Flofit-Sport

KEIPER RECARO: Orthopäd (Orthopedic), Designer Touring (design touring), Idealsitz SR, L, LX, LS 84, CS 84, CSE, T-Line, Designer Sport (design sport), C-Classic, TX, N, LS, CT, Variomed, A 8

KÖNIG: K330/370, K430/470, K530/570, K630/670, K730/770, K830/870, KS400/4000/700, CP400/4000/700, P700, RL200, CL200/400, RS/RSL 4400/8800

Be sure to contact your local Cobra, Corbeau, Flofit, König or Recaro dealer for information regarding seats recommended for the make, model and model year of your car.

HMS motorsport

3 First Avenue
Peabody, MA 01960
Toll Free (888) 536-8550
Phone (978) 532-1145
Fax (978) 532-2016

Our Service Number
(800) 884-BELT
guides you to your nearest dealer.

06/2002

Vehicle Reference List SCHROTH Profi asm

Make	Model	Mod. Year	Profi
	Model	No. Year	
AUDI			
4000	81	80-87	S
5000	43	80-83	S
5000 wagon	43	80-83	S
5000, -turbo	44	82-88	+
5000 quattro, -turbo quattro	44 Q	84-88	+
100, 200	44	88-91	+
Coupé, GT	85	82-87	S
Coupé, 4000 CS quattro, 80, 90	89	88-89	+
not Audi Quattro			
V 8	D11	88-94	+
A4	B5	01-	+
ACURA			
RSX	S	02-	+
BMW			
1602-2002, not convertible		68-76	S
3-series	E21	77-83	S
3-series			
-sedan		86-91	
Mod.-No.: AB54/64, AE54/64, AD23, AA23, AB03, AB93, AE03, AF93, AJ93			S
with uncovered anchor point C			+
with covered anchor point C			+
-M3 ¹⁵⁾	AK03	87-92	+
-convertible ¹⁵⁾		86-91	+
Mod.-No.: BB23, BA73		92-	+
-318i - 325is ¹⁹⁾			
Mod.-No.: BE53, CA53, BA73, BF73, BF43, CB43, B13			+
5-series			
Mod.-No.: E12		72-77	S
Mod.-No.: DK73/83, DC74/84		82-88	S
-M5	DC93	82-88	S
Mod.-No.: HC23, HD23/53/63		89-95	+
-M5	HD93	89-95	+
6-series			
Mod.-No.: EC74, EC84		76-89	S
-M6	EE14	76-89	S
7-series			
Mod.-No.: FH74, FG24		78-86	S
with uncovered anchor point C			S
with covered anchor point C			S
Mod.-No.: GB43, GC43, GC83, D83		87-94	+
DAIHATSU			
Rocky	FF31, FF32	90-	S
DODGE			
Neon Sedan, only 4-door	S27, S47, S67	94-	+
FORD			
Mustang, only LX-version		85-93	+
Mod.-No.: 26, 27, 28, 40, 41, 44			
Mustang, only GT-version		85-93	S
Mod.-No.: 27, 28, 42, 45	60,62,64	89-	+
Thunderbird			
Taurus		86-95	S
Mod.-No.: 29, 30, 39, 40, 50, 52, 53, 55, 57, 58			
GEO			
Metro	MS2,MR2	89-94	no install
Tracker	E18, J18	89-	no install
seat with integrated headrest			no install
seat without integrated headrest			no install
HONDA			
Civic		92-	+
Mod.-No.: EH234, EH236, EH246, EH338	EJ222, EJ122	93-	no install
Civic Coupé, only 2-door			no install
Prelude		83-92	+

For indexes see Legend of Vehicle Reference List.

For indexes see Legend of Vehicle Reference List.

Make	Model	Mod.	Profi
Model	No.	Year	
JEEP CHRYSLER Wrangler ¹⁷⁾	Y19, Y29	92-	no install
MAZDA 323	BF22, BF23	87-89	S
626 Mod.-No.: GC22, GC24, GC31	HC22	-87 88-91	S no install
929 RX 7, not convertible	FC33	86-91	no install
MERCUR Sierra ¹²⁾ Scorpio ¹²⁾	80 81	86-89 88-89	+ +
MERCURY Sable Mod.-No.: 50, 53, 55, 58, 80, 87		86-95	S
MERCEDES 190 Mod.-No.: DB26, DB28, DA24, DA28, DA29, DA34 230 - 300 200 -300 sedan Mod.-No.: EA30, EA26, EB33, EB24, ED30, EA28, EA32 200 C-300 CE Mod.-No.: EA50, EA51, EA52 200 T-300 TE Mod.-No.: EB93, EA90, ED90, EA92 260 - 560 SE, 300 SDL, 300 SLD-T Mod.-No.: CA35, CA39, CB35, CB34 380 SEC - 560 SEC	123	84-93 77-85 85-95 88-95 87- 80-91 84-91 81-91	+ + + + + S S
MITSUBISHI Cordia		83-87	no install
NISSAN Sentra, only Coupé 200 SX, only hatchback version Stanza Maxima Pathfinder	B24 S26 T21, T23 U11 D14, D16, D17	87-90 -88 86-89 86-89 87-	no install no install no install S
PLYMOUTH Premier,Colt, only notchback version	A26, A36, A46	84-88	S
PONTIAC Lemans, only version without retractor at doorsill	TX2,TN2, TS2	88-	+
PORSCHE 911 924 944 928		65- 77-82 83- 78-	S S S S
RENAULT R5, LeCar		76-83	S

For indexes see Legend of Vehicle Reference List.

Make	Model	Mod.	Profi
Model	No.	Year	
SUBARU Justy Sedan XT	A72, A73, A83 C42, C43, C53, C56 X42, X43, X75	87- 86- 86-90	no install no install no install
SUZUKI Suzuki Swift Suzuki Sidekick	AC TC,TA,TD	90-94 89-	S no install
TOYOTA Starlet Corolla Mod.-No.: E82E, E83E, E84E Celica, not convertible Mod.-No.: T63C-T67C, T64L-T67L, T68M Camry Landcruiser, only with short and middle wheelbase 4-Runner, only 5-door Mod.-No.: N27V, N37W		81-84 -87 86-89 87-91 85- 89- 90-	no install no install no install S no install no install
VOLKSWAGEN Beetle Rabbit Beetle ^{27), 35)} Jetta I Scirocco I Golf Jetta II Golf III, Jetta III Golf convertible Golf IV, 2-door ^{27), 35)} Jetta ²⁷⁾ Jetta station ²⁷⁾ Dasher Passat sedan, -station Scirocco II Corrado	11 17 1C 17, 1G 16, 1G 1H 15 9B 9M 9M 31 53 50	60-79 75-84 02- 80-84 75-81 85-92 85-92 93- 80-95 02- 02- 02- 76-81 89- 82-88 90-95	S S + S S + + + S ¹⁰⁾ + + + S + + S ¹⁰⁾ +
VOLVO 240, 260, not station wagon 740, not station wagon 760, not station wagon	DL, GL, 240 740 760	75-93 85-92 83-92	S S S

For indexes see Legend of Vehicle Reference List.